

Coordonnées de points		
MAT	X	Y
83	153,3256,89	915,6780,39
84	153,323,3,48	915,6661,3,54
87	153,3263,26	915,67670,85
88	153,3260,33	915,6660,36
89	153,3247,71	915,6649,96
90	153,32243,39	915,7649,24
429	153,32335,81	915,67663,23



Coordonnées de points		
MAT	X	Y
83	153,3256,89	915,6780,39
84	153,323,3,48	915,6661,3,54
87	153,3263,26	915,67670,85
88	153,3260,33	915,6660,36
89	153,3247,71	915,6649,96
90	153,32243,39	915,7649,24
429	153,32335,81	915,67663,23

Coordonnées de points		
MAT	X	Y
83	153,3256,89	915,6780,39
84	153,323,3,48	915,6661,3,54
87	153,3263,26	915,67670,85
88	153,3260,33	915,6660,36
89	153,3247,71	915,6649,96
90	153,32243,39	915,7649,24
429	153,32335,81	915,67663,23

